









Instrukcja montażowa

DENZEL Kontener 3S








Kod	Wymiary				Pakiet
001	492	361	16/32	1	1/1
002	492	361	16/32	1	1/1
003	393	336	16	1	1/1
004	387	160	16	1	1/1
005	336	100	16	3	1/1
008	300	100	16	3	1/1
009	300	100	16	3	1/1
012	459	365	16/32	1	1/1
013	387	160	16	2	1/1
017	512	443	2,5	1	1/1
018	305	360	2,5	3	1/1
Akcesoria				1	1/1




Akcesoria:

32x f1 Ø8x30	14x r1 15x12	14x r16 Ø5x24	6x e1 Ø7x50
2x k37	15x l1	61x p25 Ø3.5x16	3x c44
18x p52 Ø3x16	3x lb-300	3x j1	9x l2
8x s2	2x k26	1x z1	6x s1








4






5







6




7




8





9




10



11



12



13

s2	s1
	
x8	x6

